Ferrari F430 Fault Code Guide

544 lookup entries grouped by control system. Match the code and module to your scan report. Use the PDF viewer’s Find command to locate a code.

Source pagination refers to F430 Error Codes-1.pdf. Model-year and controller software applicability are unspecified in that reference. Use vehicle-specific service information when diagnosing a fault.

F1 gearbox

Code	Module / bank	Source fault label	Source page
D0601	Selespeed Gearbox	CAN MESSAGES TRANSMISSION ECU	63
D0701	Selespeed Gearbox	CAN MESSAGES RECEIVED FROM ENGINE CHECK	63
D0706	Selespeed Gearbox	CAN MESSAGES RECEIPT FROM BRAKING NODE	63
P0600	Selespeed Gearbox	CAN ERROR_CODE CAN	62
P0715	Selespeed Gearbox	GEARBOX INPUT REVOLUTIONS	60
P0720	Selespeed Gearbox	VEHICLE SPEED	60
P0725	Selespeed Gearbox	ENGINE RPM	60
P1710	Selespeed Gearbox	CLUTCH POSITION SENSOR	61
P1720	Selespeed Gearbox	OIL PRESSURE SENSOR	61
P1730	Selespeed Gearbox	PUMP RELAY DRIVER	61
P1735	Selespeed Gearbox	SELF-POWERING RELAY DRIVER	61
P1741	Selespeed Gearbox	ENGAGEMENT POTENTIOMETER	61
P1742	Selespeed Gearbox	SELECTION POTENTIOMETER	61
P1745	Selespeed Gearbox	SWITCH UP	61
P1746	Selespeed Gearbox	SWITCH STBY	61
P1747	Selespeed Gearbox	REVERSE GEAR SWITCH	61
P1748	Selespeed Gearbox	SWITCH DOWN	61
P1749	Selespeed Gearbox	BATTERY VOLTAGE	61
P1750	Selespeed Gearbox	SELECTION SV 1	61
P1751	Selespeed Gearbox	SPEED SELECTION SV2	61
P1752	Selespeed Gearbox	SPEED SELECTION SV3	61

Code	Module / bank	Source fault label	Source page
P1755	Selespeed Gearbox	IGNITION ENABLE RELAY DRIVER	61
P1756	Selespeed Gearbox	SV FOR UNEVEN GEAR ENGAGEMENT	61
P1757	Selespeed Gearbox	SV FOR EVEN GEAR ENGAGEMENT	61
P1758	Selespeed Gearbox	CLUTCH SV	61
P1759	Selespeed Gearbox	REVERSE GEAR LIGHTS' RELAY DRIVER	62
P1760	Selespeed Gearbox	FOOT BRAKE PEDAL SWITCH CAN	62
P1764	Selespeed Gearbox	SAFETY MICRO ERROR	62
P1765	Selespeed Gearbox	GROUND_DETACHME NT ERROR	62
P1766	Selespeed Gearbox	RESET_ERR	62
P1767	Selespeed Gearbox	EEPROM ERROR	62
P1770	Selespeed Gearbox	GEAR ENGAGEMENTS WITH WRONG SHIFTS	62
P1771	Selespeed Gearbox	GEARBOX INPUT HIGH RPM	62
P1772	Selespeed Gearbox	OPPOSITE GEAR ENGAGEMENT	62
P1773	Selespeed Gearbox	CLUTCH BEYOND PIS	62
P1774	Selespeed Gearbox	CLUTCH HYDRAULIC FAILURE	62
P1775	Selespeed Gearbox	GEAR RELEASE FAILED	62
P1790	Selespeed Gearbox	CLUTCH POSITION PRIMARY_VAC SENSOR	62

E-Diff

Code	Module / bank	Source fault label	Source page
6001	Differential	BATTERY VOLTAGE < 5V A	2
6002	Differential	BATTERY VOLTAGE	2
6003	Differential	BATTERY VOLTAGE>16V A	2
6004	Differential	KL15 PLAUSIBILITY	2
6005	Differential	RESET DUE TO SUDDEN POWER SUPPLY SHORTAGE	2
6006	Differential	PRESSURE SENSOR	2
6007	Differential	PUMP RELAY CONNECTION A	3
6008	Differential	SYSTEM RECHARGE	3

Code	Module / bank	Source fault label	Source page
6009	Differential	LOW SYSTEM PRESSURE	3
6010	Differential	HIGH SYSTEM PRESSURE	3
6011	Differential	EXTERNAL ACCUMULATOR SYSTEM	3
6012	Differential	PRESSURE LOCK SENSOR	3
6013	Differential	THE VOLTAGE OF THE ZERO LOCK SENSOR IS OUT OF RANGE	3
6014	Differential	OVERHEATING MAGNETIC VALVE’S DRIVER DEACTIVATION	3
6015	Differential	MAGNETIC VALVE CONNECTION A	2
6016	Differential	PLAUSIBILITY OF MAGNETIC VALVE CURRENT AND LOCK PRESSURE	3
6017	Differential	CHECK: PRESSURE" DEVIATION TOO HIGH	3
6018	Differential	CLUTCH SYSTEM MODERATE OVERHEAT	3
6019	Differential	CLUTCH SYSTEM HIGH OVERHEAT	3
6020	Differential	ECU SUDDEN RESET	3
6021	Differential	ECU ERROR A	3
6022	Differential	EEPROM ERROR	3
6023	Differential	ERROR: ECU" TEMPERATURE MEASUREMENT A	3
6024	Differential	BUS CAN OFF	2
6025	Differential	N_MOT E TABSNM	3
6026	Differential	VRD_LH_ASR E VRD_RH_ASR	4
6027	Differential	KUP2	4
6028	Differential	LOW PRIORITY CAN SIGNALS MISSING	4
6029	Differential	HIGH PRIORITY CAN SIGNALS MISSING	4
6030	Differential	CAN SIGNALS MISSING	4
6031	Differential	INCOMPLETE VEHICLE CODING	4

Motronic engine control

Code	Module / bank	Source fault label	Source page
P0030	Motronic LH / Motronic RH	RH FRONT LAMBDA SENSOR	4, 28

Code	Module / bank	Source fault label	Source page
P0031	Motronic LH / Motronic RH	RH FRONT LAMBDA SENSOR	4, 28
P0032	Motronic LH / Motronic RH	RH FRONT LAMBDA SENSOR	4, 28
P0036	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	4, 28
P0037	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	4, 28
P0038	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	4, 28
P0040	Motronic LH / Motronic RH	RH-B AND LH-B FRONT LAMBDA SENSORS RH	4, 29
P0041	Motronic LH / Motronic RH	RH-B AND LH-B REAR LAMBDA SENSORS RH	4, 29
P0050	Motronic LH / Motronic RH	LH FRONT LAMBDA SENSOR	4, 29
P0051	Motronic LH / Motronic RH	LH FRONT LAMBDA SENSOR	4, 29
P0052	Motronic LH / Motronic RH	LH FRONT LAMBDA SENSOR	4, 29
P0056	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	4, 29
P0057	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	4, 29
P0058	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	4, 29
P0071	Motronic LH / Motronic RH	AIR TEMPERATURE SENSOR	4, 29
P0101	Motronic LH / Motronic RH	AIR FLOW METER	4, 29
P0102	Motronic LH / Motronic RH	AIR FLOW METER	5, 29
P0103	Motronic LH / Motronic RH	AIR FLOW METER	5, 29
P0106	Motronic LH / Motronic RH	BAROMETRIC PRESSURE	5, 29
P0107	Motronic LH / Motronic RH	BAROMETRIC PRESSURE	5, 29
P0108	Motronic LH / Motronic RH	BAROMETRIC PRESSURE	5, 29
P0110	Motronic LH / Motronic RH	INTAKE AIR TEMPERATURE	5, 29
P0111	Motronic LH / Motronic RH	INTAKE AIR TEMPERATURE	5, 29
P0112	Motronic LH / Motronic RH	INTAKE AIR TEMPERATURE	5, 29
P0113	Motronic LH / Motronic RH	INTAKE AIR TEMPERATURE	5, 29
P0115	Motronic LH / Motronic RH	WATER TEMPERATURE SENSOR	5, 30
P0116	Motronic LH / Motronic RH	WATER TEMPERATURE SENSOR	5, 30
P0117	Motronic LH / Motronic RH	WATER TEMPERATURE SENSOR	5, 30
P0118	Motronic LH / Motronic RH	WATER TEMPERATURE SENSOR	5, 30
P0121	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR 1	6, 30

Code	Module / bank	Source fault label	Source page
P0122	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR 1	6, 30
P0123	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR 1	6, 30
P0130	Motronic LH / Motronic RH	RH FRONT LAMBDA SENSOR	6, 30
P0132	Motronic LH / Motronic RH	FRONT LAMBDA SENSOR	6, 30
P0133	Motronic LH / Motronic RH	RH FRONT LAMBDA SENSOR	6, 30
P0135	Motronic LH / Motronic RH	RH FRONT LAMBDA SENSOR	6, 30
P0136	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 30
P0137	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 30
P0138	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 30
P0139	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 30
P0140	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 30
P0141	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 31
P0150	Motronic LH / Motronic RH	RH REAR LAMBDA SENSOR	6, 31
P0152	Motronic LH / Motronic RH	FRONT LAMBDA SENSOR	6, 31
P0153	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	6, 31
P0155	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0156	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0157	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0158	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0159	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0160	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0161	Motronic LH / Motronic RH	LH REAR LAMBDA SENSOR	7, 31
P0170	Motronic LH / Motronic RH	FUEL-AIR MIXTURE RATIO SELF- LEARNING, RH BANK	7, 31
P0171	Motronic LH / Motronic RH	FUEL-AIR MIXTURE RATIO SELF- LEARNING, RH BANK	7, 31
P0172	Motronic LH / Motronic RH	FUEL-AIR MIXTURE RATIO SELF- LEARNING, RH BANK	7, 32
P0173	Motronic LH (listed only under LH in this source)	FUEL-AIR MIXTURE RATIO SELF- LEARNING, LH BANK	7
P0174	Motronic LH / Motronic RH	FUEL-AIR MIXTURE RATIO SELF- LEARNING, LH BANK	7, 32
P0175	Motronic LH / Motronic RH	FUEL-AIR MIXTURE RATIO SELF- LEARNING, LH BANK	8, 32

Code	Module / bank	Source fault label	Source page
P0201	Motronic LH / Motronic RH	CYLINDER 1 INJECTOR	8, 32
P0202	Motronic LH / Motronic RH	CYLINDER 2 INJECTOR	8, 32
P0203	Motronic LH / Motronic RH	CYLINDER 3 INJECTOR	8, 32
P0204	Motronic LH / Motronic RH	CYLINDER 4 INJECTOR	8, 32
P0205	Motronic LH / Motronic RH	CYLINDER 5 INJECTOR	8, 32
P0206	Motronic LH / Motronic RH	CYLINDER 6 INJECTOR	8, 32
P0207	Motronic LH / Motronic RH	CYLINDER 7 INJECTOR	8, 32
P0208	Motronic LH / Motronic RH	CYLINDER 8 INJECTOR	8, 32
P0219	Motronic LH / Motronic RH	ENGINE REVOL.	8, 32
P0221	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR 2	8, 32
P0222	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR 2	8, 33
P0223	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR 2	8, 33
P0230	Motronic LH / Motronic RH	FUEL PUMP RELAY	8, 33
P0261	Motronic LH / Motronic RH	CYLINDER 1 INJECTOR	8, 33
P0262	Motronic LH / Motronic RH	CYLINDER 1 INJECTOR	8, 33
P0264	Motronic LH / Motronic RH	CYLINDER 2 INJECTOR	8, 33
P0265	Motronic LH / Motronic RH	CYLINDER 2 INJECTOR	8, 33
P0267	Motronic LH / Motronic RH	CYLINDER 3 INJECTOR	9, 33
P0268	Motronic LH / Motronic RH	CYLINDER 3 INJECTOR	9, 33
P0270	Motronic LH / Motronic RH	CYLINDER 4 INJECTOR	9, 33
P0271	Motronic LH / Motronic RH	CYLINDER 4 INJECTOR	9, 33
P0273	Motronic LH / Motronic RH	CYLINDER 5 INJECTOR	9, 33
P0274	Motronic LH / Motronic RH	CYLINDER 5 INJECTOR	9, 33
P0276	Motronic LH / Motronic RH	CYLINDER 6 INJECTOR	9, 33
P0277	Motronic LH / Motronic RH	CYLINDER 6 INJECTOR	9, 33
P0279	Motronic LH / Motronic RH	CYLINDER 7 INJECTOR	9, 33
P0280	Motronic LH / Motronic RH	CYLINDER 7 INJECTOR	9, 33
P0282	Motronic LH / Motronic RH	CYLINDER 8 INJECTOR	9, 33
P0283	Motronic LH / Motronic RH	CYLINDER 8 INJECTOR	9, 33

Code	Module / bank	Source fault label	Source page
P0300	Motronic LH / Motronic RH	INJECTION/IGNITION SYSTEM	9, 33
P0301	Motronic LH / Motronic RH	CYLINDER 1 MISFIRE	9, 33
P0302	Motronic LH / Motronic RH	CYLINDER 2 MISFIRE	9, 33
P0303	Motronic LH / Motronic RH	CYLINDER 3 MISFIRE	9, 34
P0304	Motronic LH / Motronic RH	CYLINDER 4 MISFIRE	9, 34
P0305	Motronic LH / Motronic RH	CYLINDER 5 MISFIRE	9, 34
P0306	Motronic LH / Motronic RH	CYLINDER 6 MISFIRE	9, 34
P0307	Motronic LH / Motronic RH	CYLINDER 7 MISFIRE	10, 34
P0308	Motronic LH / Motronic RH	CYLINDER 8 MISFIRE	10, 34
P0327	Motronic LH / Motronic RH	RH DETONATION SENSOR 1	10, 34
P0328	Motronic LH / Motronic RH	RH DETONATION SENSOR 1	10, 34
P0332	Motronic LH / Motronic RH	RH DETONATION SENSOR 2	10, 34
P0333	Motronic LH / Motronic RH	RH DETONATION SENSOR 2	10, 34
P0335	Motronic LH / Motronic RH	ENGINE RPM SENSOR A	10, 34
P0336	Motronic LH / Motronic RH	ENGINE RPM SENSOR A	10, 34
P0337	Motronic LH / Motronic RH	ENGINE RPM SENSOR A	10, 34
P0338	Motronic LH / Motronic RH	ENGINE RPM SENSOR A	10, 34
P0340	Motronic LH / Motronic RH	RH STAGE SENSOR	10, 34
P0341	Motronic LH / Motronic RH	RH STAGE SENSOR	10, 34
P0342	Motronic LH / Motronic RH	RH STAGE SENSOR	10, 34
P0343	Motronic LH / Motronic RH	RH STAGE SENSOR	10, 34
P0345	Motronic LH / Motronic RH	LH STAGE SENSOR	10, 35
P0346	Motronic LH / Motronic RH	LH STAGE SENSOR	10, 35
P0347	Motronic LH / Motronic RH	LH STAGE SENSOR	10, 35
P0348	Motronic LH / Motronic RH	LH STAGE SENSOR	10, 35
P0351	Motronic LH / Motronic RH	CYLINDER 1 COIL PRIMARY WINDING	10, 35
P0352	Motronic LH / Motronic RH	CYLINDER 2 COIL PRIMARY WINDING	10, 35
P0353	Motronic LH / Motronic RH	CYLINDER 3 COIL PRIMARY WINDING	10, 35
P0354	Motronic LH / Motronic RH	CYLINDER 4 COIL PRIMARY WINDING	10, 35

Code	Module / bank	Source fault label	Source page
P0355	Motronic LH / Motronic RH	CYLINDER 5 COIL PRIMARY WINDING	11, 35
P0356	Motronic LH / Motronic RH	CYLINDER 6 COIL PRIMARY WINDING	11, 35
P0357	Motronic LH / Motronic RH	CYLINDER 7 COIL PRIMARY WINDING	11, 35
P0358	Motronic LH / Motronic RH	CYLINDER 8 COIL PRIMARY WINDING	11, 35
P0385	Motronic LH / Motronic RH	ENGINE RPM SENSOR B	11, 35
P0386	Motronic LH / Motronic RH	ENGINE RPM SENSOR B	11, 35
P0387	Motronic LH / Motronic RH	ENGINE RPM SENSOR B	11, 35
P0388	Motronic LH / Motronic RH	ENGINE RPM SENSOR B	11, 35
P0411	Motronic LH / Motronic RH	SECONDARY AIR SYSTEM	11, 35
P0412	Motronic LH / Motronic RH	SECONDARY SOLENOID VALVE CONTROL CIRCUIT	11, 35
P0413	Motronic LH / Motronic RH	SECONDARY SOLENOID VALVE CONTROL CIRCUIT	11, 35
P0414	Motronic LH / Motronic RH	SECONDARY SOLENOID VALVE CONTROL CIRCUIT	11, 35
P0421	Motronic LH / Motronic RH	RH CATALYTIC CONVERTER HEATING	11, 36
P0426	Motronic LH / Motronic RH	RH CATALYTIC CONVERTOR TEMPERATURE SENSOR	11, 36
P0427	Motronic LH / Motronic RH	RH CATALYTIC CONVERTOR TEMPERATURE SENSOR	11, 36
P0428	Motronic LH / Motronic RH	RH CATALYTIC CONVERTOR TEMPERATURE SENSOR	11, 36
P0431	Motronic LH / Motronic RH	LH CATALYTIC CONVERTOR HEATING	12, 36
P0436	Motronic LH / Motronic RH	LH CATALYTIC CONVERTOR TEMPERATURE SENSOR	12, 36
P0437	Motronic LH / Motronic RH	LH CATALYTIC CONVERTOR TEMPERATURE SENSOR	12, 36
P0438	Motronic LH / Motronic RH	LH CATALYTIC CONVERTOR TEMPERATURE SENSOR	12, 36
P0440	Motronic LH / Motronic RH	ANTI-EVAPORATION CONTROL SYSTEM	12, 36
P0442	Motronic LH / Motronic RH	ANTI-EVAPORATION CONTROL SYSTEM	12, 36
P0443	Motronic LH / Motronic RH	ANTI-EVAPORATION SYSTEM CONTROL SOLENOID VALVE	12, 36
P0444	Motronic LH / Motronic RH	ANTI-EVAPORATION SYSTEM CONTROL SOLENOID VALVE	12, 36
P0445	Motronic LH / Motronic RH	ANTI-EVAPORATION SYSTEM CONTROL SOLENOID VALVE	12, 36
P0446	Motronic LH / Motronic RH	CANISTER AIR INTAKE VALVE CONTROL CIRCUIT	12, 37
P0447	Motronic LH / Motronic RH	CANISTER AIR INTAKE VALVE CONTROL CIRCUIT	12, 37
P0448	Motronic LH / Motronic RH	CANISTER AIR INTAKE VALVE CONTROL CIRCUIT	12, 37
P0449	Motronic LH / Motronic RH	CANISTER AIR INTAKE VALVE CONTROL CIRCUIT	12, 37

Code	Module / bank	Source fault label	Source page
P0450	Motronic LH / Motronic RH	TANK PRESSURE SENSOR	13, 37
P0451	Motronic LH / Motronic RH	TANK PRESSURE SENSOR	13, 37
P0452	Motronic LH / Motronic RH	TANK PRESSURE SENSOR	13, 37
P0453	Motronic LH / Motronic RH	TANK PRESSURE SENSOR	13, 37
P0455	Motronic LH / Motronic RH	ANTI-EVAPORATION CONTROL SYSTEM	13, 37
P0456	Motronic LH / Motronic RH	ANTI-EVAPORATION CONTROL SYSTEM	13, 37
P0460	Motronic LH / Motronic RH	FUEL LEVEL SENSOR	13, 37
P0461	Motronic LH / Motronic RH	FUEL LEVEL SENSOR	13, 37
P0462	Motronic LH / Motronic RH	FUEL LEVEL SENSOR	13, 38
P0463	Motronic LH / Motronic RH	FUEL LEVEL SENSOR	13, 38
P0475	Motronic LH / Motronic RH	EXHAUST BY-PASS VALVE	13, 38
P0477	Motronic LH / Motronic RH	EXHAUST BY-PASS VALVE	13, 38
P0478	Motronic LH / Motronic RH	EXHAUST BY-PASS VALVE	13, 38
P0480	Motronic LH / Motronic RH	FAN 1 CONTROL CIRCUIT	13, 38
P0500	Motronic LH / Motronic RH	CAR SPEED	14, 38
P0501	Motronic LH / Motronic RH	CAR SPEED	14, 38
P0502	Motronic LH / Motronic RH	CAR SPEED	14, 38
P0506	Motronic LH / Motronic RH	ENGINE PARAMETERS AT IDLE SPEED	14, 38
P0507	Motronic LH / Motronic RH	ENGINE PARAMETERS AT IDLE SPEED	14, 38
P0560	Motronic LH / Motronic RH	BATTERY VOLTAGE	14, 38
P0562	Motronic LH / Motronic RH	BATTERY VOLTAGE	14, 38
P0563	Motronic LH / Motronic RH	BATTERY VOLTAGE	14, 38
P0571	Motronic LH / Motronic RH	BRAKE SWITCH	14, 38
P0600	Motronic LH / Motronic RH	RH-B AND LH-B CAN LINE ERROR CAN	14, 38
P0604	Motronic LH / Motronic RH	RAM INTERNAL ERROR	14, 39
P0605	Motronic LH / Motronic RH	ROM INTERNAL ERROR	14, 39
P0606	Motronic LH / Motronic RH	MICROPROCESSOR INTERNAL ERROR	14, 39
P0645	Motronic LH / Motronic RH	CLUTCH - AC COMPRESSOR RELAY CONTROL	14, 39
P0646	Motronic LH / Motronic RH	CLUTCH - AC COMPRESSOR RELAY CONTROL	14, 39

Code	Module / bank	Source fault label	Source page
P0647	Motronic LH / Motronic RH	CLUTCH - AC COMPRESSOR RELAY CONTROL	14, 39
P0654	Motronic LH / Motronic RH	ENGINE RPM OUTPUT SIGNAL	15, 39
P0660	Motronic LH / Motronic RH	MODULAR MANIFOLD SOLENOID VALVE	15, 39
P0661	Motronic LH / Motronic RH	MODULAR MANIFOLD SOLENOID VALVE	15, 39
P0662	Motronic LH / Motronic RH	MODULAR MANIFOLD SOLENOID VALVE	15, 39
P073	Motronic RH	FUEL-AIR MIXTURE RATIO SELF- LEARNING, LH BANK	32
P1034	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR	15, 39
P1035	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR	15, 39
P1036	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR	15, 39
P1037	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR	15, 39
P1040	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR	15, 39
P1041	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR	15, 39
P1043	Motronic LH / Motronic RH	CYL. 7-8-9 FRONT LAMBDA SENSOR RH	15, 39
P1045	Motronic LH / Motronic RH	BACK OX. SENSOR (RH.CYL.4-5-6 AND LH.CYL.7-8-9) RH	15, 40
P1048	Motronic LH / Motronic RH	CYL. 7-8-9 FRONT LAMBDA SENSOR	15, 40
P1049	Motronic LH / Motronic RH	CYL. 7-8-9 FRONT LAMBDA SENSOR	15, 40
P1101	Motronic LH / Motronic RH	LH-B AIR-FLOW METER	15, 40
P1104	Motronic LH / Motronic RH	LH-B AIR-FLOW METER	15, 40
P1106	Motronic LH / Motronic RH	LH-B AIR-FLOW METER	15, 40
P1108	Motronic LH / Motronic RH	LH AIR TEMPERATURE SENSOR	15, 40
P1109	Motronic LH / Motronic RH	LH AIR TEMPERATURE SENSOR	16, 40
P1111	Motronic LH / Motronic RH	LH AIR TEMPERATURE SENSOR	16, 40
P1112	Motronic LH / Motronic RH	LH AIR TEMPERATURE SENSOR	16, 40
P1127	Motronic LH / Motronic RH	Fuel adaptation reported rich; source heading says Bank 2 / Lower	16, 40
P1128	Motronic LH / Motronic RH	Fuel adaptation reported lean; source heading says Bank 2 / Lower	16, 40
P1129	Motronic LH / Motronic RH	CYL. 7-8-9 SELF- LEARNING OF AIR FUEL MIXTURE RATIO AT LOW ENGINE SPEED	16, 40
P1130	Motronic LH / Motronic RH	CYL. 7-8-9 SELF- LEARNING OF AIR FUEL MIXTURE RATIO AT LOW ENGINE SPEED	16, 41

Code	Module / bank	Source fault label	Source page
P1131	Motronic LH / Motronic RH	THROTTLE POSITION SENSOR	16, 41
P1132	Motronic LH / Motronic RH	LH-B THROTTLE POTENTIOETER	16, 41
P1133	Motronic LH / Motronic RH	LH-B ENVIRONMENT TEMPERATURE SENSOR	16, 41
P1135	Motronic LH / Motronic RH	RH-B FRONT LAMBDA SENSOR HEATING CIRCUIT	17, 41
P1136	Motronic LH / Motronic RH	LH-B ADDITIONAL AIR SELF-LEARNING	17, 41
P1137	Motronic LH / Motronic RH	LH-B ADDITIONAL AIR SELF-LEARNING	17, 41
P1138	Motronic LH / Motronic RH	CYL. 7-8-9 ADDITIONAL AIR SELF-LEARNING	17, 41
P1139	Motronic LH / Motronic RH	CYL. 7-8-9 ADDITIONAL AIR SELF-LEARNING	17, 41
P1140	Motronic LH / Motronic RH	LH BANK SELF- LEARNING OF AIR FUEL MIXTURE RATIO AT LOW ENGINE SPEED A	17, 42
P1141	Motronic LH / Motronic RH	LH BANK SELF- LEARNING OF AIR FUEL MIXTURE RATIO AT LOW ENGINE SPEED A	17, 42
P1142	Motronic LH / Motronic RH	CYL.7-8-9 SELF- LEARNING OF AIR FUEL MIXTURE RATIO AT LOW ENGINE SPEED A	17, 42
P1143	Motronic LH / Motronic RH	CYL.7-8-9 SELF- LEARNING OF AIR FUEL MIXTURE RATIO AT LOW ENGINE SPEED A	18, 42
P1145	Motronic LH / Motronic RH	ECU INTERNAL ERROR	18, 42
P1146	Motronic LH / Motronic RH	ACCELERATOR PEDAL POTENTIOMETER 1.	18, 42
P1147	Motronic LH / Motronic RH	ACCELERATOR PEDAL POTENTIOMETER 1.	18, 42
P1148	Motronic LH / Motronic RH	LH-B ECU INTERNAL ERROR	18, 42
P1149	Motronic LH / Motronic RH	ACCELERATOR PEDAL POTENTIOMETER 1.	18, 42
P1150	Motronic LH / Motronic RH	ACCELERATOR PEDAL POTENTIOMETER 2	18, 42
P1151	Motronic LH / Motronic RH	ACCELERATOR PEDAL POTENTIOMETER 2	18, 42
P1161	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE SELF- LEARNING	18, 43
P1162	Motronic LH / Motronic RH	SAFETY SPRING AT THE LH-B MOTOR- DRIVEN THROTTLE OPENING	18, 43
P1163	Motronic LH / Motronic RH	SAFETY SPRING AT THE LH-B MOTOR- DRIVEN THROTTLE CLOSING	18, 43
P1164	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE SELF- LEARNING UNSUCCESSFUL	18, 43
P1165	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE SELF- LEARNING	19, 43
P1166	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POSITION AMPLIFIER ERROR	19, 43

Code	Module / bank	Source fault label	Source page
P1167	Motronic LH / Motronic RH	LH-B THROTTLE MOTOR CONTROL POWER STAGE FAULT	19, 43
P1171	Motronic LH / Motronic RH	THROTTLE POSITION DRIFT IN RELATION TO LH PEDAL B REQUEST	19, 43
P1175	Motronic LH / Motronic RH	Motor-driven throttle position outside the allowed range	19, 43
P1178	Motronic LH / Motronic RH	THROTTLE POSITION SELF-LEARNING	19, 43
P1179	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE RETURN SPRING FAILURE A	19, 44
P1180	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE RETURN SPRING FAILURE A	19, 44
P1181	Motronic LH / Motronic RH	THROTTLE POSITION SELF-LEARNING	19, 44
P1182	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE SELF- LEARNING	19, 44
P1183	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE	19, 44
P1184	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE	19, 44
P1185	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE	20, 44
P1186	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE	20, 44
P1187	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE	20, 44
P1188	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE SELF- LEARNING	20, 44
P1189	Motronic LH / Motronic RH	ACCELERATOR PEDAL POTENTIOMETER	20, 44
P1190	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POTENTIOMETER 1	20, 44
P1191	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POTENTIOMETER 1	20, 44
P1192	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POTENTIOMETER 1	20, 44
P1193	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POTENTIOMETER 2	20, 44
P1194	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POTENTIOMETER 2	20, 44
P1195	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE POTENTIOMETER 2	20, 44
P1196	Motronic LH / Motronic RH	MOTOR DRIVEN THROTTLE	20, 45
P1197	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE SELF- LEARNING	20, 45
P1198	Motronic LH / Motronic RH	LH FRONT LAMBDA SENSOR	20, 45
P1249	Motronic LH / Motronic RH	LH-B ENVIRONMENT PRESSURE SENSOR	20, 45
P1250	Motronic LH / Motronic RH	LH-B ENVIRONMENT PRESSURE SENSOR	21, 45
P1251	Motronic LH / Motronic RH	LH-B ENVIRONMENT PRESSURE SENSOR	21, 45
P1252	Motronic LH / Motronic RH	ECU INTERNAL ERROR	21, 45

Code	Module / bank	Source fault label	Source page
P1253	Motronic LH / Motronic RH	ECU INTERNAL ERROR	21, 45
P1254	Motronic LH / Motronic RH	ECU INTERNAL ERROR	21, 45
P1255	Motronic LH / Motronic RH	ECU INTERNAL ERROR	21, 45
P1256	Motronic LH / Motronic RH	LH-B FUEL SELF- LEARNING	21, 45
P1257	Motronic LH / Motronic RH	LH-B FUEL SELF- LEARNING	21, 45
P1258	Motronic LH / Motronic RH	LH-B FUEL SELF- LEARNING	21, 46
P1259	Motronic LH / Motronic RH	CYL. 7-8-9 FUEL SELF- LEARNING	21, 46
P1260	Motronic LH / Motronic RH	CYL. 7-8-9 FUEL SELF- LEARNING	21, 46
P1261	Motronic LH / Motronic RH	CYL. 7-8-9 FUEL SELF- LEARNING	22, 46
P1263	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR HEATING CHECK	22, 46
P1267	Motronic LH / Motronic RH	ECU INTERNAL ERROR	22, 46
P1268	Motronic LH / Motronic RH	ECU INTERNAL ERROR	22, 46
P1269	Motronic LH / Motronic RH	ECU INTERNAL ERROR	22, 46
P1270	Motronic LH / Motronic RH	ECU INTERNAL ERROR	22, 46
P1271	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR HEATING CHECK	22, 46
P1272	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR HEATING CHECK	22, 46
P1273	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR HEATING CHECK	22, 46
P1278	Motronic LH / Motronic RH	CYL.7-8-9 FRONT LAMBDA SENSOR HEATING CHECK	22, 46
P1279	Motronic LH / Motronic RH	CYL.7-8-9 FRONT LAMBDA SENSOR HEATING CHECK	28, 53
P1280	Motronic LH / Motronic RH	CYL.7-8-9 FRONT LAMBDA SENSOR HEATING CHECK	22, 46
P1281	Motronic LH / Motronic RH	CYL.7-8-9 FRONT LAMBDA SENSOR HEATING CHECK	22, 47
P1285	Motronic LH / Motronic RH	CYL.7-8-9 REAR LAMBDA SENSOR HEATING CHECK	22, 47
P1287	Motronic LH / Motronic RH	RH-B FRONT LAMBDA SENSOR	22, 47
P1288	Motronic LH / Motronic RH	LH-B FRONT LAMBDA SENSOR	22, 47
P1289	Motronic LH / Motronic RH	SAFETY SPRING AT THE LH-B MOTOR- DRIVEN THROTTLE OPENING	22, 47
P1290	Motronic LH / Motronic RH	SAFETY SPRING AT THE LH-B MOTOR- DRIVEN THROTTLE CLOSING	23, 47
P1291	Motronic LH / Motronic RH	LH-B MOTOR-DRIVEN THROTTLE RANGE CHECK	23, 47

Code	Module / bank	Source fault label	Source page
P1292	Motronic LH / Motronic RH	SAFETY SPRING AT THE RH-B MOTOR- DRIVEN THROTTLE OPENING	23, 47
P1293	Motronic LH / Motronic RH	SAFETY SPRING AT THE RH-B MOTOR- DRIVEN THROTTLE CLOSING	23, 47
P1294	Motronic LH / Motronic RH	RH-B MOTOR-DRIVEN THROTTLE RANGE CHECK	23, 47
P1296	Motronic LH / Motronic RH	TORQUE LIMITING DEVICE ACTIVATION	23, 47
P1297	Motronic LH / Motronic RH	LH-B TORQUE LIMITING DEVICE	23, 47
P1298	Motronic LH / Motronic RH	RH-B TORQUE COMPARISON CHECK	23, 47
P1299	Motronic LH / Motronic RH	LH-B TORQUE COMPARISON CHECK	23, 48
P1323	Motronic LH / Motronic RH	RH STAGE SENSOR	23, 48
P1324	Motronic LH / Motronic RH	RH STAGE SENSOR	23, 48
P1337	Motronic LH / Motronic RH	ENGINE REVOLUTION SENSOR	23, 48
P1338	Motronic LH / Motronic RH	LH-B RPM SENSOR	23, 48
P1339	Motronic LH / Motronic RH	LH STAGE SENSOR	23, 48
P1340	Motronic LH / Motronic RH	LH STAGE SENSOR	24, 48
P1341	Motronic LH / Motronic RH	ECU INTERNAL ERROR	24, 48
P1342	Motronic LH / Motronic RH	LH-B ECU INTERNAL ERROR ECU	24, 48
P1382	Motronic LH / Motronic RH	LH DETONATION SENSOR 2	24, 48
P1383	Motronic LH / Motronic RH	LH DETONATION SENSOR 1	24, 48
P1384	Motronic LH / Motronic RH	LH DETONATION SENSOR 1	24, 48
P1385	Motronic LH / Motronic RH	LH DETONATION SENSOR 2	24, 48
P1386	Motronic LH / Motronic RH	DETONATION CONTROL SYSTEM	24, 48
P1387	Motronic LH / Motronic RH	LH-B DETONATION SENSOR MONITORING	24, 48
P1388	Motronic LH / Motronic RH	DETONATION CONTROL SYSTEM	24, 48
P1390	Motronic LH / Motronic RH	LH-B DETONATION SENSOR MONITORING TOPOLOGICAL >	24, 48
P1393	Motronic LH / Motronic RH	DETONATION CONTROL SYSTEM	24, 48
P1394	Motronic LH / Motronic RH	LH-B DETONATION SENSOR MONITORING	24, 48
P1419	Motronic LH / Motronic RH	CANISTER PURGE SYSTEM	24, 48
P1420	Motronic LH / Motronic RH	CANISTER PURGE SYSTEM	24, 49
P1421	Motronic LH / Motronic RH	CANISTER PURGE SYSTEM	24, 49

Code	Module / bank	Source fault label	Source page
P1422	Motronic LH / Motronic RH	CANISTER PURGE SYSTEM	24, 49
P1423	Motronic LH / Motronic RH	LH-B CATALYTIC CONVERTER EFFICIENCY WHEN WARM A	24, 49
P1424	Motronic LH / Motronic RH	CYL 7-8-9 CATALYTIC CONVERTER EFFICIENCY WHEN WARM A	24, 49
P1427	Motronic LH / Motronic RH	LH-B CANISTER PURGE SOLENOID VALVE CIRCUIT	24, 49
P1428	Motronic LH / Motronic RH	LH-B CANISTER PURGE SOLENOID VALVE CIRCUIT	25, 49
P1439	Motronic LH / Motronic RH	LH-B SECONDARY AIR INJECTION SYSTEM	25, 49
P1443	Motronic LH / Motronic RH	SECONDARY AIR INJECTION SYSTEM, LH BANK	25, 49
P1444	Motronic LH / Motronic RH	CYL.7-8-9 SECONDARY AIR INJECTION SYSTEM	25, 49
P1446	Motronic LH / Motronic RH	Catalyst temperature protection active	25, 49
P1450	Motronic LH / Motronic RH	SECONDARY AIR PUMP RELAY CONTROL	25, 49
P1451	Motronic LH / Motronic RH	SECONDARY AIR PUMP RELAY CONTROL	25, 49
P1452	Motronic LH / Motronic RH	SECONDARY AIR PUMP RELAY CONTROL	25, 49
P1454	Motronic LH / Motronic RH	PROTECTION ACTIVATION FOR LH BANK CATALYTIC CONVERTERS	25, 49
P1463	Motronic LH / Motronic RH	LH-B FUEL LEVEL SENSOR	25, 49
P1464	Motronic LH / Motronic RH	LH-B FUEL LEVEL SENSOR	25, 50
P1465	Motronic LH / Motronic RH	LH-B FUEL LEVEL SENSOR	25, 50
P1466	Motronic LH / Motronic RH	LH-B FUEL LEVEL SENSOR	25, 50
P1467	Motronic LH / Motronic RH	RH-B THROTTLE ANGLE CHECK SIGNAL	25, 50
P1468	Motronic LH / Motronic RH	RH-B THROTTLE ANGLE CHECK SIGNAL	25, 50
P1469	Motronic LH / Motronic RH	RH-B THROTTLE ANGLE CHECK SIGNAL	25, 50
P1481	Motronic LH / Motronic RH	RH SECONDARY AIR SOLENOID VALVE	26, 50
P1482	Motronic LH / Motronic RH	LH SECONDARY AIR SOLENOID VALVE	26, 50
P1483	Motronic LH / Motronic RH	FAN 1 RELAY CONTROL	26, 50
P1484	Motronic LH / Motronic RH	FAN 1 RELAY CONTROL	26, 50
P1487	Motronic LH / Motronic RH	LH-B SECONDARY AIR VALVE	26, 50
P1488	Motronic LH / Motronic RH	CYL 7-8-9 SECONDARY AIR VALVE	26, 50
P1501	Motronic LH / Motronic RH	FUEL PUMP RELAY 1 CONTROL	26, 50
P1504	Motronic LH / Motronic RH	LH-B FUEL PUMP 1 RELAY	26, 50

Code	Module / bank	Source fault label	Source page
P1505	Motronic LH / Motronic RH	LH-B FUEL PUMP 1 RELAY	26, 50
P1506	Motronic LH / Motronic RH	LH-B FUEL PUMP 1 RELAY	26, 50
P1518	Motronic LH / Motronic RH	IDLE CONTROL SYSTEM	26, 50
P1519	Motronic LH / Motronic RH	IDLE CONTROL SYSTEM	26, 50
P1537	Motronic LH / Motronic RH	CAR SPEED	26, 51
P1538	Motronic LH / Motronic RH	CAR SPEED	26, 51
P1539	Motronic LH / Motronic RH	CAR SPEED	26, 51
P1540	Motronic LH / Motronic RH	CLUTCH INFORMATION ERROR	26, 51
P1541	Motronic LH / Motronic RH	FUEL PUMP RELAY 1 CONTROL	26, 51
P1542	Motronic LH / Motronic RH	CLUTCH DATA	26, 51
P1543	Motronic LH / Motronic RH	FUEL PUMP RELAY 2 CONTROL	26, 51
P1544	Motronic LH / Motronic RH	FUEL PUMP RELAY 2 CONTROL	27, 51
P1545	Motronic LH / Motronic RH	FUEL PUMP RELAY 2 CONTROL	27, 51
P1546	Motronic LH / Motronic RH	LH-B FUEL PUMP 2 RELAY	27, 51
P1547	Motronic LH / Motronic RH	LH-B FUEL PUMP 2 RELAY	27, 51
P1548	Motronic LH / Motronic RH	LH-B FUEL PUMP 2 RELAY	27, 51
P1556	Motronic LH / Motronic RH	FUEL TANK EMPTY ERROR	27, 51
P1557	Motronic LH / Motronic RH	FUEL TANK EMPTY ERROR	27, 51
P1560	Motronic LH / Motronic RH	LH-B BATTERY VOLTAGE	27, 51
P1562	Motronic LH / Motronic RH	LH-B BATTERY VOLTAGE	27, 51
P1563	Motronic LH / Motronic RH	LH-B BATTERY VOLTAGE	27, 51
P1569	Motronic LH / Motronic RH	LH-B BRAKE SWITCH	27, 51
P1570	Motronic LH / Motronic RH	IMMOBILIZER	27, 51
P1571	Motronic LH / Motronic RH	RH-B IMMOBILIZER	27, 52
P1586	Motronic LH / Motronic RH	Engine shutdown requested after a major gearbox fault	27, 52
P1587	Motronic LH / Motronic RH	ENGINE STOP FROM LH-B GEARBOX ECU	27, 52
P1602	Motronic LH / Motronic RH	PERMANENT POWER SUPPLY	27, 52
P1604	Motronic LH / Motronic RH	LH-B ECU INTERNAL ERROR	27, 52
P1605	Motronic LH / Motronic RH	LH-B ECU INTERNAL ERROR	27, 52

Code	Module / bank	Source fault label	Source page
P1609	Motronic LH / Motronic RH	ROADBED SENSOR A	28, 52
P1610	Motronic LH / Motronic RH	ROADBED SENSOR	28, 52
P1611	Motronic LH / Motronic RH	PERMANENT POWER SUPPLY	28, 52
P1613	Motronic LH / Motronic RH	FAULTY ECU	28, 52
P1614	Motronic LH / Motronic RH	LH-B ECU INTERNAL ERROR	28, 52
P1617	Motronic LH / Motronic RH	ROADBED SENSOR A	28, 52
P1619	Motronic LH / Motronic RH	ROADBED SENSOR	28, 52
P1620	Motronic LH / Motronic RH	K LINE	28, 52
P1621	Motronic LH / Motronic RH	K LINE	28, 52
P1622	Motronic LH / Motronic RH	K LINE	28, 52
P1626	Motronic LH / Motronic RH	ASR TIMEOUT ASR	28, 52
P1627	Motronic LH / Motronic RH	F1 GEARBOX TIMEOUT	28, 52
P1628	Motronic LH / Motronic RH	MONITORING OF MESSAGES BETWEEN THE TWO RH-B BANKS CAN	28, 52
P1630	Motronic LH / Motronic RH	RH-B ECU CONFIGURATION CHECK	28, 53
P1632	Motronic LH / Motronic RH	CAN MESSAGES TIMEOUT FROM LH-B GEARBOX ECU	28, 53

Dashboard

Code	Module / bank	Source fault label	Source page
B9001	Dashboard	Engine ground input	1
B9002	Dashboard	OIL PRESSURE SENSOR	1
B9003	Dashboard	OIL PRESSURE SENSOR	1
B9004	Dashboard	ALTERNATOR FAILURE	1
B9005	Dashboard	SUSPENSIONS FAILURE A FAIL STATUS	1
B9006	Dashboard	STATISTICAL DATA CORRUPTED	1
B9007	Dashboard	OIL PRESSURE IN ALARM CONDITION	1
B9008	Dashboard	OIL TEMPERATURE IN ALARM CONDITION	1
B9009	Dashboard	WATER TEMPERATURE IN ALARM CONDITION	1
B900A	Dashboard	CHECK ENGINE FAILURE	1

Code	Module / bank	Source fault label	Source page
B900B	Dashboard	SLOW DOWN FAILURE	1
B900C	Dashboard	BRAKE FAILURE A	1
B900D	Dashboard	LUGGAGE COMPARTMENT OUTPUT A	1
B900E	Dashboard	REAR FOG LIGHT OUTPUT A	1
B900F	Dashboard	HAZARD LIGHT OUTPUT A	1
B9010	Dashboard	HEATED REAR WINDOW OUTPUT A	1
B9011	Dashboard	LUGGAGE COMP. LOCK OUTPUT A	1
B9012	Dashboard	OUTPUTS FOR WINDSCREEN WIPER TIMING AND RESETTING A	1
B9013	Dashboard	BATTERY VOLTAGE	1
B9014	Dashboard	POWER OUTPUT FOR KAVLICO OIL PRESSURE SENSOR A	2
B9015	Dashboard	EXTERNAL EEPROM IN ERROR CONDITION	2
B9016	Dashboard	EEPROM CORRUPTED	2
UD601	Dashboard	NO CAN MESSAGES RECEIVED FROM ESP ECU	2
UD602	Dashboard	NO CAN MESSAGES RECEIVED FROM F1 GEARBOX	2
UD603	Dashboard	NO CAN MESSAGES RECEIVED FROM MOTRONIC ECU	2
UD604	Dashboard	NO CAN MESSAGES RECEIVED FROM TPMS ECU	2
UD605	Dashboard	NO CAN MESSAGES RECEIVED FROM DIFFERENTIAL ECU	2
UD606	Dashboard	NO CAN MESSAGES RECEIVED FROM NVO ECU	2
UD607	Dashboard	TRANSMISSION ERROR ON	2
UD608	Dashboard	TRANSMISSION ERROR ON	2

Suspension

Code	Module / bank	Source fault label	Source page
C1001	NCS Suspension Node	ECU IN ERROR CONDITION ECU	53
C1011	NCS Suspension Node	BATTERY VOLTAGE	53
C1021	NCS Suspension Node	ACCELERATION SENSOR FOR FRONT RIGHT-HAND WHEEL	53
C1022	NCS Suspension Node	ACCELERATION SENSOR FOR FRONT LEFT-HAND WHEEL	53
C1031	NCS Suspension Node	ACCELERATION SENSOR FOR FRONT RIGHT-HAND BODY	53

Code	Module / bank	Source fault label	Source page
C1032	NCS Suspension Node	ACCELERATION SENSOR FOR FRONT LEFT-HAND BODY	53
C1033	NCS Suspension Node	ACCELERATION SENSOR FOR REAR RIGHT-HAND BODY	53
C1201	NCS Suspension Node	FRONT RIGHT-HAND VALVE ERROR	53
C1202	NCS Suspension Node	FRONT LEFT-HAND VALVE ERROR	54
C1203	NCS Suspension Node	REAR RIGHT-HAND VALVE ERROR	54
C1204	NCS Suspension Node	REAR LEFT-HAND VALVE ERROR	54
C1301	NCS Suspension Node	SENSOR 1 SUPPLY VOLTAGE	54
C1302	NCS Suspension Node	SENSOR 2 SUPPLY VOLTAGE	54
U1700	NCS Suspension Node	NO COMMUNICATION WITH NBC	54
U1701	NCS Suspension Node	NO COMMUNICATION WITH NCM	54
U1706	NCS Suspension Node	NO COMMUNICATION WITH NFR	54
U1711	NCS Suspension Node	NO COMMUNICATION WITH NCR	54
U1712	NCS Suspension Node	NO COMMUNICATION WITH NAS	54

Brakes

Code	Module / bank	Source fault label	Source page
C1100	NFR Node Brakes	EOL CONFIGURATION NOT PROGRAMMED	54
C1103	NFR Node Brakes	EOL CONFIGURATION CHANGED	55
C1200	NFR Node Brakes	FRONT RH SPEED SENSOR: ELECTRICAL" ERROR	55
C1201	NFR Node Brakes	FRONT RH SPEED SENSOR: ERROR	55
C1205	NFR Node Brakes	FRONT LH SPEED SENSOR: ELECTRICAL" ERROR	55
C1206	NFR Node Brakes	FRONT LH SPEED SENSOR: ERROR	55
C1210	NFR Node Brakes	REAR RH SPEED SENSOR: ELECTRICAL" ERROR	55
C1211	NFR Node Brakes	REAR RH SPEED SENSOR: ERROR	56
C1215	NFR Node Brakes	REAR LH SPEED SENSOR: ELECTRICAL" ERROR	55
C1216	NFR Node Brakes	REAR LH SPEED SENSOR: ERROR	56
C1226	NFR Node Brakes	RH FRONT ABS EXHAUST VALVE	56
C1231	NFR Node Brakes	RH REAR ABS INTAKE VALVE	56

Code	Module / bank	Source fault label	Source page
C1236	NFR Node Brakes	LH FRONT ABS EXHAUST VALVE	56
C1241	NFR Node Brakes	LH FRONT ABS INTAKE VALVE	56
C1246	NFR Node Brakes	RH REAR ABS EXHAUST VALVE	57
C1251	NFR Node Brakes	RH FRONT ABS INTAKE VALVE	57
C1256	NFR Node Brakes	LH REAR ABS EXHAUST VALVE	57
C1260	NFR Node Brakes	PRIMARY VALVE 1	57
C1261	NFR Node Brakes	LH REAR ABS INTAKE VALVE	57
C1262	NFR Node Brakes	PRIMARY VALVE 2	57
C1265	NFR Node Brakes	PILOT VALVE 1 (USV1)	58
C1266	NFR Node Brakes	SCAVENGE PUMP	58
C1267	NFR Node Brakes	PILOT VALVE 2 (USV2)	58
C1276	NFR Node Brakes	SOLENOID VALVE INPUT	58
C1340	NFR Node Brakes	FOOT BRAKE PEDAL SWITCH	58
C1341	NFR Node Brakes	BRAKE LIGHT ACTIVATION RELAY (PAR. IGN.)	58
C1355	NFR Node Brakes	SIDE ACCELERATION SENSOR (AY SENSOR)	58
C1360	NFR Node Brakes	YAW RATE SENSOR	59
C1460	NFR Node Brakes	PRESSURE SENSOR	59
C1500	NFR Node Brakes	WHEELS SPEED PLAUSIBILITY ERROR (LAMBDA 6)	59
C1504	NFR Node Brakes	ACTUATION DEFECT	59
C1505	NFR Node Brakes	STEERING ANGLE SENSOR	59
C1506	NFR Node Brakes	TEMPORARY INTERFERENCE	59
C1507	NFR Node Brakes	SERIAL LINE	59
C1508	NFR Node Brakes	STEERING ANGLE SENSOR NOT CALIBRATED	59
C1520	NFR Node Brakes	BUS CAN	59
C1521	NFR Node Brakes	ENGINE CAN MESSAGES ERROR	59
C1522	NFR Node Brakes	NO COMMUNICATION WITH FAILURE WARNING LIGHTS (NQS) CAN	59
C1523	NFR Node Brakes	CAN MESSAGES ERROR (ACC)	59
C1607	NFR Node Brakes	ECU ERROR	59

Code	Module / bank	Source fault label	Source page
C1802	NFR Node Brakes	SUPPLY VOLTAGE	59
C1881	NFR Node Brakes	VARIANT CODING	60

Steering wheel node

Code	Module / bank	Source fault label	Source page
9001	NVO Steering Wheel Node	PASSENGER COMPARTMENT LIGHTING ACTIVATION	60
9002	NVO Steering Wheel Node	REAR CENTRAL CEILING LIGHT ACTIVATION	60
9003	NVO Steering Wheel Node	REAR, LEFT-HAND POWER WINDOW MOTOR’S CURRENT	60
9007	NVO Steering Wheel Node	CROWN LED ERROR	60